

## GUARANTEED NEVER TO HURT OR FALL OUT



**1** Insert sound tunnel.

**2** Twist into place.



For a Getting Started video featuring TwistLock® in action, scan the QR code or visit [yurbuds.com/inspire-twistlock](http://yurbuds.com/inspire-twistlock)

Our earbuds fit differently than other brands in that they are designed to fill the bowl of your ear with the sound tunnel extending down into your ear canal. They are not meant to be pushed down into the ear canal. The back of the bud should brace lightly against the back of the bowl of your ear.

## FIT ENHANCERS TO EARPHONE



**1** Wrap right enhancer around right earphone. Repeat for left side.



**2** Start with the left bud and rotate sound tunnel between 3-4 o'clock position. Adjust for comfort.



**3** Repeat with the right bud and rotate sound tunnel between 8-9 o'clock position. Adjust for comfort.

TO CLEAN ENHANCERS: Remove & wash with warm soapy water

## NEED ANOTHER SIZE?



If the earbuds are not perfect, send us your picture for a FREE personalized fit. Take a photo of your current earbuds in your ear and email it to [orders@yurbuds.com](mailto:orders@yurbuds.com). **yurbuds will send you the correct size for free, or exchange your model for a better-fitting option.**

**CONTACT US:**  
900 Spruce St. Suite 550  
St. Louis, MO 63102, USA  
[www.yurbuds.com/contact](http://www.yurbuds.com/contact)

**CALL US TOLL FREE:**  
(888)YUR-BUDI or  
(888)987-2831

PRODUCT RETURNS: Please contact yurbuds for customer support before returning to store.

### LIMITED YURBUDS WARRANTY

yurbuds™ purchased from authorized retailers are warranted against defects in materials and workmanship for a period of ONE year from the date of purchase of the product. If a defect exists, yurbuds™, at its discretion and to the extent permitted by law will (1) repair the product at no charge, or (2) replace the product if it is irreparable. This warranty excludes damage resulting from abuse, accident, modifications or other causes that are not defects in materials and workmanship. **THIS WARRANTY DOES NOT AFFECT YOUR STATUTORY RIGHTS.** Visit [yurbuds.com](http://yurbuds.com) for our complete product warranty policy.

The use of mobile devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products. For details on GUARANTEED NEVER TO FALL OUT see [yurbuds.com/legal](http://yurbuds.com/legal).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:  
1. This device may not cause interference, and  
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Model: 30004  
QDID: B019076

## DUAL PURPOSE EARPHONES



### STEREO FOR SOUND

Use both earphones for a premium listening experience while being active.

GREAT FOR:



GYM



HOME



OFFICE



### MONO FOR MOBILITY

For easy, on-the-go use detach the second earphone and experience single-ear sound.

GREAT FOR:



CAR




TRAVEL



OUTDOOR ACTIVITIES

## POWER & PAIR

### POWERING ON/OFF

1 Press and Hold the  Power Button.

-  GREEN FLASH WITH AUDIBLE ALERT: Power on, Not Paired
-  EXTENDED BLUE FLASH WITH AUDIBLE ALERT: Powered Off

### PAIRING

2 FIRST TIME USE: HYBRID Wireless will automatically be set to pairing mode. Skip to step 4 to complete set-up.

CONSECUTIVE USES: Begin with HYBRID Wireless powered off and your Bluetooth device powered on and in search mode.

3 Press and hold  Pairing Button.\*

4 Select "yurbuds HYBRID Wireless" on your device.

-  BLUE & GREEN FLASH: Pairing Mode
-  BLUE FLASH: Power on, Paired

\*Green light flashes rapidly when pairing in low power mode



## MUSIC & CALLS

### TRACK

Pause/Play:  
1 Click

Next Track:  
Double Press


Previous:  
Long Press

### CALL

Answer/End Calls:  
1 Click

Voice Activation\*:  
2 Clicks

Redial:  
Long Press



### VOLUME

Volume Down:  
1 Click

Volume Up:  
1 Click

\*Compatible with iOS only; Commands are not operational when listening to music



## CHARGE

1 Locate the charging port at the side of the right earphone.

2 Lift cover for USB charging port


3 Plug in device with the provided charging cable



-  FLASHING GREEN: Indicates Charging
-  SOLID GREEN: Indicates Fully Charged

### CHARGE STATUS

▶ On-Screen Indicator\* shows level of charge



### AUDIBLE ALERTS

Status provided once when battery is low

FOR MORE INSTRUCTIONAL DETAILS FOR YURBUDS HYBRID WIRELESS, PLEASE VISIT YURBUDS.COM



CONNECT WITH US.

